




OPERATING INSTRUCTIONS PERSONAL BLENDER MODEL NO.: TSBL-PB250



220V-240V 50/60Hz 300W

Thanks for choosing our product. In order to use this product better, please read this manual carefully before using the product. Please keep it well after reading.

Precautions (Important!)

1. This product is only used to stir juice, please do not use it for other purposes.
2. Do not use the product without liquid or water (recommended to have a minimum of 40% of the total volume of liquid).
3. The rated voltage of this product is 220V, please do not use it under other voltages.
4. Do not wet the main unit, power cord, plug, etc. to prevent leakage.
5. Do not use if the product fails or the power cord is damaged.
6. The blade is sharp and should be used with caution.
7. Children are prohibited from using and should be kept out of reach of children.
8. Please remove the power in time after use.
9. This product is for home use only.
10. Never immerse the product in water.


First time use

Check the product for damage, such as power cord and mixing cup, etc.

Clean the parts that come into contact with the food (knife assembly, cup cover assembly, sport bottle).

Home use only
Save the instructions properly

Composition and use:



- A: Cap
B: Mixing cup
C: Knife base
D: Main body


1. Add material and tighten the knife base



2. Put in to the main body,blending



3. Remove the cup and replace the cap



Using methods(compared to the figure above)

Add material(like figure 1)

Add the material to the cup and tighten the knife base clockwise

Blending(like figure 2)

1. Put the mixing cup after tightening the knife base into the main body by reversing(knife base is under).
2. The mixing cup tighten the main body by clockwise.Press and hold the front button to start stirring.
3. After the stirring is completed, release the button, turn the mixing cup anticlockwise to loosen the main body and take out the cup.

Replace the cap(like figure 3)

1. Turn anticlockwise to loosen and remove the knife base.
2. Screw the cap clockwise onto the mixing cup.

Clean

Wash the mixing cup,knife base and cap after use.
It can use the wet cloth to wipe the main body.Never immerse the main body in the water.

Attention

1. This product is not intended for use by persons with physical, sensory or intellectual disabilities (including children) who must use this product with supervision and instructions to ensure safety.
2. Children are prohibited from using.
3. The product should be operated for less than 1 min in a single continuous operation to protect the motor and ensure the lifetime of the product.

Other data

Voltage	220-240V 50/60Hz 300W
Model	TSBL-PB250
Capacity	2×600ml
Knife	4 blade
Power cord	Exposed line length: 1.2m